Hall-current sensor "CSLA2CD"

Pins from left to right

Closed plastic With text



Open plastic Magnet visible



+ Positive V_d supply

* measurement pin

- GND

Measurement should be performed between measurement pin * and GND – $\it Example$

If the sensor is supplied with 8 volts, when no current is measured by the sensor, it simply divides it's supply voltage by 2. The voltage measured will then be 8/2 = 4 V.

For every A that the sensor measures it will output 0,033 V.

The conversion formula will the be as follows:

Measured
$$A = \frac{V_{Sensor} - 2 V}{0.033 V}$$

So if the Sensor voltage is 5 V the amps will be 30,30 A in the wire through the sensor.

Measured A:
$$\frac{5 V - 4 V}{0.033 V} = 30,30 A$$

Source: http://www.scienceshareware.com/how-to-measure-AC-DC-current-with-a-hall-effect-clamp-.htm